

**1** PLACE THE REMOTE CONTROL TO BE CLONED IN FRONT OF THE "AIR4", AT A DISTANCE OF ABOUT 2 CENTIMETRES.




**2** PRESS AND HOLD DOWN **BUTTON 1** ON THE "AIR4" REMOTE CONTROL.






**3** AT THE SAME TIME PRESS **BUTTON 4** FOUR TIMES.

**4** RELEASE BOTH BUTTONS OF "AIR4" REMOTE CONTROL.



**5** "AIR4" REMOTE CONTROL LED WILL FLASH BRIEFLY ABOUT EVERY 2 SEC.

**6** PRESS AND HOLD DOWN THE BUTTON TO BE COPIED FROM THE ORIGINAL REMOTE CONTROL AND WAIT FOR THE "AIR4" LED TO START **FLASHING RAPIDLY**, WHICH CONFIRMS THAT THE CODE HAS BEEN ACQUIRED. RELEASE THE ORIGINAL REMOTE CONTROL'S BUTTON.



**7** WHILE THE LED IS FLASHING, PRESS THE "AIR4" BUTTON TO WHICH THE CODE MUST BE TRANSFERRED AND HOLD DOWN UNTIL THE LED GOES OUT.