

FREE Software Update - PSA Pincode Read ADS229 - Code D745912AD

January 2017



Advanced Diagnostics is pleased to announce the release of a free update for ADS229 PSA Pincode Read software for various vehicles worldwide.

What does the software do?

ADS229 has been expanded to cover a wider range of PSA vehicles manufactured from 2006 to 2016 - including vehicles fitted with a Johnson Controls BSI. ADS229 software has been significantly improved to cover bladed and proximity keys and also supports pincode reading for bladed vehicles in lost key situations.

To see the vehicle applications please refer to Info Quest.

What other software and products will I need?



MVP Pro users: one token will be deducted for pincode reading and another token will be deducted for key programming.

Not available for AD100 Pro Truck.

Contact your distributor to purchase ADS229 software now.

OFFER DETAILS

Cable	ADC250 or ADC251
Dongle	Smart Dongle or Dongle H & A
Software category	B
Other software required	ADS142
Smart card	Yes or Smart Dongle

© All the brands and product names mentioned in this flyer are registered trademarks exclusive property of authorized manufacturers. Said trademarks or trade names are nominated only for the purposes of information in order to be rapidly identified.

www.silca.biz - www.silca-automotive.com - www.advanced-diagnostics.com

Software Applications

PSA Pincode Read ADS229

TABLE - EUROPE

									
Citroën® Berlingo 2 (Blade) 2007 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® C3 (Blade) 2006 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® C3 (Blade) 2006 to 2010	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® C3 Aircross (Blade) 2010 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® C3 Picasso (Blade) 2008 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Citroën® C4 (Proximity) 2011 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✓	ID46	HU83TE
Citroën® C4 Picasso (Blade) 2013 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Citroën® C4 Picasso (Prox - Slot) 2013 onwards	✓	✗	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✓	ID46	HU83TE
Citroën® C5 (Blade) 10/2004 to 2007	✓	✓	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® C5 (Blade) 2008 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® C6 (Blade) 2005 onwards	✓	✓	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® C-Elysée (Blade) 2013 to 2016	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® Dispatch 2 - BSI (Blade) 2007 onwards	✓	✓	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Citroën® DS3 (Blade) 2009 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® DS4 (Blade) All variants	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Citroën® DS4 (Proximity) All variants	✓	✗	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✓	ID46	VA2TE

Important Note: To prevent damage to the Smart Dongle, ensure that the ignition is turned off when connecting the tester to the vehicle.

© All the brands and product names mentioned in this flyer are registered trademarks exclusive property of authorized manufacturers. Said trademarks or trade names are nominated only for the purposes of information in order to be rapidly identified.

Software Applications

PSA Pincode Read ADS229

TABLE - EUROPE

									
Citroën® DS5 (Prox - Slot) All variants	✓	✗	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✓	ID46	HU83TE
Citroën® Jumpy - BSI (Blade) 2008 onwards	✓	✓	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Citroën® Jumpy 2 (Blade) 2008 onwards	✓	✓	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Fiat® Scudo (Blade) 2008 onwards	✓	✓	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	SIP22TE
Peugeot® 207 (Blade) 2006 to 2012	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Peugeot® 207cc (Blade) 2006 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Peugeot® 208 (Blade) 2012 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Peugeot® 301 (Blade) 2013 to 2016	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Peugeot® 307 Mk1 Ph2 (Blade) 2005 to 2010	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Peugeot® 308 (Blade) 2007 to 2013	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Peugeot® 308 (Blade) 2013 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Peugeot® 508 (Blade) 2011 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	VA2TE
Peugeot® 508 (Blade) 2012 onwards	✓	✓	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE
Peugeot® 508 (Proximity) All variants	✓	✗	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✓	ID46	VA2TE
Peugeot® 607 (Blade) 2005 onwards	✓	Automatic procedure	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	NE78TE
Peugeot® 807 (Blade) 2006 onwards	✓	✓	✓	✓	ADC250 or ADC251	Dongle H and A or Smart Dongle	✗	ID46	HU83TE

Important Note: To prevent damage to the Smart Dongle, ensure that the ignition is turned off when connecting the tester to the vehicle.

© All the brands and product names mentioned in this flyer are registered trademarks exclusive property of authorized manufacturers. Said trademarks or trade names are nominated only for the purposes of information in order to be rapidly identified.

Software Applications

PSA Pincode Read ADS229

TABLE - EUROPE


















































































									
Peugeot® 2008 (Blade) 2013 onwards		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® 3008 (Blade) 2007 onwards					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® 4008 (Blade) All variants					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	MIT11RTE
Peugeot® 5008 (Blade) All variants		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® Expert (Blade) 2007 onwards					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® Partner CAN (Blade) 2008 onwards		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE
Peugeot® RCZ (Blade) 2010 onwards		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Toyota® Proace (Blade) 2013 onwards		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE

TABLE - ASIA

									
Peugeot® 207cc (Blade) 2006 onwards					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE
Peugeot® 301 (Blade) 2013 to 2016		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE
Peugeot® 508 (Blade) 2011 onwards		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® 508 (Proximity) All variants		Manual procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® 3008 (Blade) 2013 to 2015		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE
Peugeot® Partner (Blade) 2008 onwards					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE

Important Note: To prevent damage to the Smart Dongle, ensure that the ignition is turned off when connecting the tester to the vehicle.

© All the brands and product names mentioned in this flyer are registered trademarks exclusive property of authorized manufacturers. Said trademarks or trade names are nominated only for the purposes of information in order to be rapidly identified.

Software Applications

PSA Pincode Read ADS229

TABLE - AFRICA






















									
Citroën® C2 (Blade) 2005 to 2009		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE

TABLE - SOUTH AMERICA

									
Citroën® C3 (Blade) 2006 onwards					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE
Citroën® C3 (Blade) 2012 onwards		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE
Citroën® C4 Picasso (Blade) 2007 to 2012		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® 207 (Blade) 2012 onwards		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE
Peugeot® 208 (Blade) 2013 onwards					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® 308 (Blade) 2011 onwards		Automatic procedure			ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE
Peugeot® 508 (Proximity) 2012 onwards					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	HU83TE
Peugeot® 3008 (Blade) All variants					ADC250 or ADC251	Dongle H and A or Smart Dongle		ID46	VA2TE

Important Note: To prevent damage to the Smart Dongle, ensure that the ignition is turned off when connecting the tester to the vehicle.

© All the brands and product names mentioned in this flyer are registered trademarks exclusive property of authorized manufacturers. Said trademarks or trade names are nominated only for the purposes of information in order to be rapidly identified.

www.silca.biz - www.silca-automotive.com - www.advanced-diagnostics.com