

A SIMPLIFIED PROCEDURE TO ACTIVATE THE REMOTE CONTROL IN THE RELEVANT RECEIVER ONLY IF THE “VIA RADIO OR REMOTE SAVE” FUNCTION IS ACTIVATED”.

IF NOT, CONSULT THE INSTRUCTIONS FOR THE ORIGINAL REMOTE CONTROL.

NOTE: DO NOT USE THE ORIGINAL REMOTE CONTROL BEFORE ACTIVATING THE A.L.S. PROCEDURE ON THE SILCA AIR4 REMOTE CONTROL.

1
STAND CLOSE TO
THE AUTOMATION.



2
HOLD DOWN THE PROGRAMME
BUTTON FOR ABOUT 10 SECONDS;
RELEASE WHEN THE LED STARTS TO
FLASH.

3
WAIT UNTIL THE LED GOES OUT.



**RECEIVERS MAY HAVE THE RADIO CHANNEL DISABLED, IN SUCH CASES ENTER THE NEW REMOTE CONTROLS USING A MANUAL PROCEDURE.
FROM THAT MOMENT BOTH THE REMOTE CONTROLS (ORIGINAL AND SILCA “AIR4”) WILL WORK PROPERLY ON THE AUTOMATION.**